

GIGA AND MICRO RADIO REMOTE CONTROL SYSTEM

-PRELIMINARY-

INSTALLATION AND OPERATION MANUAL

BAZOOKA FARMSTAR 3B3071AJ.doc December 17, 2021 BF

INDEX

| DESCRIPTION | 3 |
|---------------------------------------------|----|
| OPERATION | |
| INDICATOR LEDs | 5 |
| TRANSMITTER AND RECEIVER SYNCHRONIZATION | 6 |
| CLONING | 6 |
| BATTERY CHARGING | |
| OUTPUTS | 9 |
| INPUTS | 10 |
| INSTALLATION | 10 |
| BEFORE APPLYING POWER! | 11 |
| SYSTEM TROUBLESHOOTING USING ON BOARD GATE: | 12 |
| ACCESSING THE CONTROL PANEL | 12 |
| DIAGNOSTICS | 13 |
| CALIBRATION | 14 |
| HISTOGRAM | 17 |
| SOFTWARE UPDATE | 18 |
| GATE CONFIGURATION | 19 |
| WIRING | 21 |
| ROUTINE MAINTENANCE | 22 |
| MAINTENANCE PRECAUTIONS | 22 |
| TROUBLESHOOTING | 23 |
| TROUBLESHOOTING CHART | 24 |
| ERROR CODES | 25 |
| GIGA TRANSMITTER PICTORIAL | 28 |
| MICRO TRANSMITTER PICTORIAL | 29 |
| RECEIVER PICTORIAL | 30 |
| SPECIFICATIONS | |

| INSTRUCTION TO THE USER (GIGA A | ND RECEIVER) 32 |
|----------------------------------------|-----------------|
| INSTRUCTION TO THE USER (MICRO |) |

DESCRIPTION

The GIGA AND MICRO REMOTE of is state the а art based Radio microprocessor Frequency (RF) control system. They will provide the operator the ability to wirelessly operate The operator is equipment. required to follow all OSHA www.osha.gov and other applicable safety standards when operating the equipment. Do not use high power radio devices in close proximity of this product.

The remote control system consists of: the Giga radio radio transmitter, the Micro transmitter, receiver module, associated optional and equipment such wiring as harnesses.

The Giga and Micro transmitters are equipped with pushbuttons and proportional pushbuttons for the various functions. These units run on a 3.7V rechargeable battery.

The system's radio receiver has current-regulated both proportional outputs and PWM outputs proportional to accommodate the functions available on the transmitter. All outputs are current-sourcing. It also includes on board Wi-Fi communication for system diagnostics.

OPERATION

Power must be applied to the receiver module for the system to work.

Pressing the POWER button until the red and green LEDs appear

3

will turn on the transmitter. Pressing and holding the POWER button until the LEDs stop toggling will turn off the transmitter. Pressing the POWER button will turn off all outputs as If safetv feature. the а transmitter goes out of range for more than 2 seconds, all outputs will turn off as a safety feature except for those turned on by the Micro transmitter.

To save battery life, the Giga transmitter will turn off after 5 minutes or 10 minutes if Micro if no buttons are pressed. The user must press POWER at this restore transmitter point to operation. To change the sleep following time, the use procedure:

For the Giga transmitter:

1. With the transmitter and receiver off, press and hold

| POWER | and | buttons |
|----------|------|---------|
| ENABLE | and | NOZZLE |
| ROTATE R | IGHT | |

- Keep holding until the green and red LEDs start blinking together slowly. Release buttons
- Press one of the following buttons for desired sleep time:
 - a. ROTATE BOOM RIGHT
 - 5 minutes
 - b. SECTION A DOWN 15 minutes
 - c. SECTION B IN 60 minutes
 - d. SECTION C IN 120 minutes
 - e. ENABLE sleep time disabled

For the Micro transmitter:

- 1. With the transmitter and receiver off, press and hold POWER and buttons LOAD, and AGITATE
- 2. Keep holding until the

green and red LEDs start blinking together slowly. Release buttons

- 3. Press one of the following buttons for desired sleep time:
 - a. STOP 2 minutes
 - b. AGITATE 3 minutes
 - c. ENABLE 5 minutes
 - d. LOAD 10 minutes

The Micro transmitter will also turn off automatically after 15 seconds when the receiver is off or there is no communication.

INDICATOR LEDs

The transmitter has two indicators, the red BATTERY indicator and the green TRANSMIT indicator. The green TRANSMIT indicator blinks rapidly whenever there is communication between the transmitter and the receiver. It will double-blink when no functions are used.

The red BATTERY indicator starts blinking once every second when the battery voltage is low and requires charging. Plug in the transmitter as soon as possible after seeing the low battery indicator. See BATTERY CHARGING below.

The receiver module can identify problems with the system in the form of an error code. Check the red indicator or display window on the receiver to diagnose system problems. Then, refer to the ERROR CODE this CHART in manual for explanation of the error codes. The green LED indicator will blink on the receiver during active operation and will turn on solid when Wi-Fi is connected.

TRANSMITTER AND RECEIVER SYNCHRONIZATION

Each radio remote system is designed to operate with а unique radio ID code and RF channel sequence. Each receiver is programmed to respond only to the transmitter with the ID code/RF channel correct sequence for which it is set. This feature allows multiple systems to work in close proximity to one another without interference.

In the event that a transmitter becomes damaged and a new one is needed, the receiver can be reprogrammed to respond to the new transmitter. To teach the ID code to the receiver, use the following procedure. ***Please note that if this procedure is interrupted before it has completed, the system may have intermittent operation:**

- 1. Turn the transmitter and receiver off
- Press and hold the POWER button for more than 10 seconds on the transmitter. LEDs should blink at this point
- Apply power to the receiver. Only the green
 LED should start blinking on the transmitter
- 4. Teach complete

CLONING

Warning! Only one transmitter can be on at a time, they cannot be used simultaneously! Use with caution! Occasionally, it is desirable to have more than one transmitter work with a single receiver. This is accomplished process called cloning. by a allows additional Cloning an transmitter (B) to have the

same ID code as the original transmitter (A). If this feature is desired, use the following procedure:

For the Giga transmitter:

- 1. Make sure transmitters and receiver are off
- On transmitter A, press and hold POWER button for more than 10 seconds.
 LEDs should blink at this point. Release POWER button
- 3. On transmitter B, press and hold buttons BOOM ROTATE LEFT, BOOM ROTATE RIGHT, and POWER until the LEDs start to blink. Release buttons
- Wait for a few seconds until the green LED only starts to blink on transmitter A and transmitter B.
- 5. Turn off both transmitters

6. Synchronize one of the transmitters to the receiver

For the Micro transmitter:

- 1. Make sure transmitters and receivers are off
- On transmitter A, press and hold POWER button for more than 10 seconds.
 LEDs should blink at this point. Release POWER button
- 3. On transmitter B, press and hold buttons STOP, AGITATE, and POWER until the LEDs start to blink. Release buttons
- Wait for a few seconds until the green LED only starts to blink on transmitter A and transmitter B.
- 5. Turn off both transmitters
- 6. Synchronize one of the transmitters to the receiver

If cloning feature has been invoked and is no longer

7

desired, the ID code of one of the transmitters needs to be changed. This will unclone the transmitters. If this is desired, use the following procedure:

For the Giga transmitter:

- 1. Make sure the receiver and transmitters are OFF
- 2. Press and hold buttons BOOM ROTATE LEFT, SECTION A UP, SECTION B OUT, and POWER until the LEDs start to toggle. Release buttons
- 3. Press any button again to select a new ID
- 4. Uncloning complete
- 5. Use transmitter and receiver synchronization procedure above to link the uncloned transmitter to new receivers

For the Micro transmitter:

1. Make sure the receiver and

transmitters are OFF

- Press and hold buttons AGITATE, LOAD, ENABLE, and POWER until the LEDs start to toggle. Release buttons
- 3. Press any button again to select a new ID
- 4. Uncloning complete
- 5. Use transmitter and receiver synchronization procedure above to link the uncloned transmitter to new receivers

BATTERY CHARGING

The battery can be charged by plugging the AC wall charger or DC cigarette charger into the USB or magnetic USB port. Red and green LED indicators near the charging port of the transmitter indicate the status of the charger: A red LED indicates that the battery is charging and

a green LED indicates that the battery is fully charged.

IMPORTANT BATTERY INFO

When the battery is new, the run-time of the transmitter will be shorter until it has gone through the drain/charge cycle several times. After this point, the unit's current drain should allow at least 20 hours of runtime before a recharge is needed.

The temperature that the transmitter battery is exposed to affects performance and useful life. It is strongly recommended you keep within the following limits:

- A. Charging: -4 to +86°F
- B. Operating: -20 to +122°F
- C. Storing: -4 to +86°F (lower is better)

OUTPUTS

Each of the outputs from the receiver module is designed with built-in short circuit and overload protection. The outputs can also detect a no-load or broken wire condition.

These error conditions are evident by the red LED indicator on the receiver module *or* the HISTOGRAM page on the onboard Gate.

The ON/OFF outputs will indicate an error under no load or broken wire status if NOT activated, and will detect a short IF activated. The current regulated proportional outputs will detect a no-load or short condition WHEN activated.

INPUTS

One digital input is available for CLOG signaling. It will function up to battery voltage levels. There are also two analog inputs available for AGITATE SPEED and PUMP OUT signaling. These work from 0-5V.

INSTALLATION

Refer to the WIRING CHART in this manual for hookup of the harness.

To install the receiver module, use the two mounting holes provided on the enclosure to attach it in a vertical manner with the connectors facing down. Please take extra caution not to damage internal components while installing. For high vibration applications, use shock absorbing mounts. It is advised to mount the unit as high as possible, keeping clear of metal obstructions around the antenna which might affect RF performance. Antenna extension cables are available from Kar-Tech to aid in this, if needed.

The main power to the receiver should be connected through a switched, fused line capable of a minimum of 20 amps. For best results, connect power (+) to the receiver via an auxiliary terminal of the ignition switch, PTO switch, or ignition relay. Be sure that the ground (-) is securely connected to the chassis or battery with a star washer which digs into the base metal to insure good contact.

All connections must be properly insulated to protect against shorts.

Seal all connections with a non-

conductive silicone grease to prevent corrosion.

BEFORE APPLYING POWER!

- Check power and ground for proper polarity.
- Check the wiring harness for possible shorts before connecting to output devices (i.e., valves and relays) by checking each mating pin terminal.
- Verify that the transmitter battery is fully charged.
- Read the rest of this manual.

SYSTEM TROUBLESHOOTING USING ON BOARD GATE:

The GATE creates a Wi-Fi access point which allows you to connect to any device with Wi-Fi and web browser such as smart phones, pads, or personal computers. Tt Google Chrome, supports Internet Explorer, Firefox, and IOS Safari and allows user to configure, diagnose, and troubleshoot the system. The receiver's green LED will turn solid when Wi-Fi is on connected to a device. The Wi-Fi will turn off after five minutes of no use. To turn it back on, recycle power to the receiver.

ACCESSING THE CONTROL PANEL

- 1. Turn on the power to the receiver.
- 2. Use your device and look for the available Wi-Fi networks. Α network under the of name **"BAZOOKAFARMSTAR3B** 307" should be available at this point. Connect to the network, the password is 3B3073X1.
- Once the connection is established, open a web browser on your device.
 Kar-Tech recommends using Chrome browser.
- Enter the address http://192.168.1.1 in the address bar





5. The following options are available from the main screen.

| KAR | | Help! |
|--------------------------|-------------------------|-------|
| Main Bazooka F | Screen armstar 3B307 | |
| Calibration | Histogram | |
| Diagnostics | WiFi Configuration | |
| | Software Update | |

Main Page

DIAGNOSTICS

Tap the Diagnostic button to see the diagnostic screens, which shows the present state of remote communications, and system I/O.

When the round circle next to a label is dark, the corresponding ON/OFF input or output is sensed to be active or ON.

| Diagnostic I | nput | s/Outpu | uts | |
|------------------------------------------|--------------|----------|------------|-------|
| Calibration | tome | H | logoam | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| RF Quality | | | | |
| 25 25 25 | 1007 | | RF ID: | 53831 |
| | 1000 | | | |
| RF Power | | Ga | te Channel | : 6 |
| 25% 52% 75% | 100% | | Bat | tery: |
| | | | 13. | 28 V |
| Transmitte | Digitz | I Inputs | | |
| o Stop | • | Enable | | |
| Agrate | • | road | | |
| | | | | |
| Boom Rotate Left | 0 % | g inputs | | |
| Boom Rotate Right | 0 % | | | |
| Section A Up | 61 % | | | |
| Section A Down | 0 % | | | |
| Section B Uut | 0 % | | | |
| Section C Out | 0 % | | | |
| Section C In | 0 % | | | |
| Nozzle Rotate Left Nozzle Rotate Righ | 0 % t 0 % | | | |
| | | | | |
| Receiver | Digital | Inputs | | |
| Clog Input | | | | |
| | | | | |
| Acitate Speed | 0.00 | inputs | | |
| Pump Out | 0.00 | | | |
| Proportio | onal Ou | tputs | | |
| Hydrostat A Fwd Curren | t | 0 mA | | |
| Hydrostat A Rev Curren | t | 0 mA | | |
| Hydrostat B Fwd Curren | nt | 0 mA | | |
| Hydrostat B Rev Curren | t | 0 mA | | |
| Boom Rotate Left Boom Rotate Right | | 0 % | | |
| Section A Up | | 60 % | | |
| Section A Down | | 0 % | | |
| Section B In | | 0 % | | |
| Section B OUt | | 0 % | | |
| Section C Out | | 0 % | | |
| Rotate Nozzle Left | | 0 % | | |
| Rotate Nozzle Right | | 0.% | | |
| Agitate | | 0.% | | |

Diagnostics Page

CALIBRATION

To change the configuration of the unit, tap the Calibration icon.

| KAR | |
|--------------------------------|----------------------------------|
| Calil | oration |
| Diagnostic | Iome Histogram |
| 4 | (°• |
| Output | Calibration |
| Hydrostat A Fwd | ▼ Neutral ▼ |
| Current Value: Neutral: | 600 mA |
| Hydrostat A Fwd: | 0 mA |
| Miscellaneo | ous Calibration |
| • Hy Hy Micro Enable Tin | drostat A drostat B le (s) |
| Current Value: New Value: | 5 Sec |
| Sale | |

Calibration Page

The password to gain access to the calibration page is 1262.

To adjust a proportional output's configuration, use the following procedure:

- 1. Select the output to change from the first drop-down menu
 - a.HYDROSTAT A FWD
 - Select to adjust
 - Hydrostat A FWD output
 - b.HYDROSTAT A REV-
 - Select to adjust
 - Hydrostat A REV output
 - C.HYDROSTAT B FWD
 - Select to adjust
 - Hydrostat B FWD output
 - d.HYDROSTAT B REV
 - Select to adjust
 - Hydrostat B REV output
 - e.BOOM ROTATE LEFT
 - Select to adjust
 - Boom Rotate Left output
 - f.BOOM ROTATE
 - RIGHT Select to
 - adjust Boom

| | Rotate | | Rig | jht | |
|----|---------|----|------|-----|--|
| | output | | | | |
| g. | SECTION | A | UP | _ | |
| | Select | to | adju | ıst | |
| | Section | А | . | Up | |
| | output | | | | |
| h. | SECTION | ΑI | DOWN | _ | |
| | Select | to | adju | ıst | |
| | Section | А | D٥١ | wn | |
| | output | | | | |
| i. | SECTION | В | IN | _ | |
| | | | | | |

Select to adjust Section B In output

- j.SECTION B OUT -Select to adjust Section B Out output
- k.SECTION C IN -Select to adjust Section C In output
- 1. SECTION C OUT -Select to adjust Section C Out output

m.ROTATE LEFT NOZZLE – Select to adjust Rotate Left Nozzle output

- n.ROTATE RIGHT NOZZLE - Select to
 - adjust Rotate Right Nozzle

output

- o.AGITATE Select
 to adjust Agitate
 output
- p.LOAD Select to adjust Load output
- Select the parameter of the output to change from the second dropdown menu
 - a. Neutral current to valve in mA when at neutral position
 - b. Min Minimum amount of current to valve in mA or percent %

- c. Max Maximum amount of current to valve in mA or percent %
- d. Ramp Up Time in seconds to go from Min to Max current
- e. Ramp Down Time in seconds to go from Max current to no current
- f. Frequency Dither
 frequency to valves
 in Hz (Change
 affects all outputs)
- 3. Enter the new value in the new value box
- 4. Tap the Save button to send the setting to memory

In the miscellaneous calibration area there are also these parameters available to change:

1. Hydrostat A or B -

Use the two checkboxes to choose which Hydrostat outputs to use.

- Micro Enable Time (s)

 This is the time in seconds the user has to operate a button after the enable button has been pressed.
- 3. Giga Enable Time (s) - This is the time in seconds the user has to operate a button after the enable button has been pressed.
- 4. Agitate Run Time (s) – This is the time in seconds the AGITATE output will turn on after the agitate button has been pressed.
- 5. Load Run Time (s) This is the time in seconds the LOAD output will turn on after the load

button has been pressed.

- 6. Clog speed (%) This is the percentage of the hydrostat rev output that will turn on when the clog input is high.
- 7. Prop Button Deadband (%) – This is the percent of the proportional buttons that must be pressed before the output turns on.
- 8. Enter the new value in the new value box
- 9. Tap the Save button to send the setting to memory

The lines to the right of the parameter indicate the present value of the output (if active).

Tap the Factory Settings button to return all outputs to standard values. Tap HOME to quit calibration and return to the main menu.

<u>HISTOGRAM</u>

Tap the Histogram icon to see a set of screens that show which error codes are active and how many times the specific error code has been active.

This feature can be used to troubleshoot machine wiring and other problems. Tapping the Reset button resets the error code counts. The password to reset error codes is 1262. Tap the Home button to return to the main menu.

Note: the GATE is not a precision measurement instrument. There may be delays.



Histogram Page

SOFTWARE UPDATE

The password to gain access to the software update page is

1262.

Use the Choose File button to select new software on your device with which to program the receiver. Karwill Tech have provided software in the .kar format. Once the file is selected, press the LOAD button to upload (NOTE: the file. Pop-up messages will guide user for the proper step by step procedure). Disconnect then reconnect to the network and go to software update. Then choose the correct .kar file. Press submit to load the file. Once complete, disconnect then reconnect to the network and press HOME.

Note: This feature does not work on Apple mobile or tablet products.

Note: Do not turn the receiver or the GATE off during the

upload process.

| | Help! |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------|
| Software Update | |
| Home | |
| Choose File No file chosen WARNING: Make sure you have the correct file before selting the file and pressing Load you will need to disconnect and reconnect to this WFI network. | |

Software Update Page

| | pl |
|-------------------------------------------------------------------------------------------------------------------------------------|----|
| Wi-Fi Configuration | |
| Home | |
| Wi-Fi Name(SSID) V | |
| Value: BAZOOKAFARMSTAR3B307 New Value: Value: | |
| Current Wi-Fi Power : 100% New Wi-Fi Power : 100% | |
| Broadcast SSID O Not Broadcast SSID | |
| Enable Multiple Connections | |
| NOTE: 1.1WEH Items limited to 20 characters 2. WHEH Items can only use numbers and letters 3. Channel can be set from 1 to 11 | |
| Save Factory Settings | |
| Refresh | |

Gate Configuration Page

GATE CONFIGURATION

The password to gain access to the gate configuration page

is 1262.

This page allows you to change the name (SSID) of the Wi-Fi network you are connecting to. Factory settings will rename the Wi-Fi to its original name.

If Broadcast SSID option is selected, the Wi-Fi name (SSID) is public and it will be visible to any other Wi-Fi devices. Otherwise, the Wi-Fi name (SSID) is hidden and it would require manual connection to the network.

If Enable Multiple Connections is selected, multiple connections up to 4 devices could be connected to the GATE. However, only one of the connected devices can use the GATE. If Single connection is enabled, only one device

can be connected to the GATE.

NOTE: A reconnect to the new Wi-Fi connection is needed after each change. It is advised to keep a note of the Wi-Fi name in case if Not Broadcast SSID option is selected. Forgetting the Wi-Fi name after selecting this option will require the GATE to be sent to KAR-TECH for RESET.

WIRING

| CABLE, 24 COND | 18 AWG POLY, BLACK, P/N: 020-050-2418 |
|----------------|---------------------------------------|
| COLOR | DESCRIPTION |
| RED | POWER (9-30V) |
| BLACK | GROUND |
| BLUE | BOOM ROTATE LEFT PWM OUTPUT |
| ORANGE | BOOM ROTATE RIGHT PWM OUTPUT |
| YELLOW | BOOM SECTION A UP PWM OUTPUT |
| BROWN | BOOM SECTION A DOWN PWM OUTPUT |
| RED/BLACK | BOOM SECTION B IN PWM OUTPUT |
| BLUE/BLACK | BOOM SECTION B OUT PWM OUTPUT |
| ORANGE/BLACK | BOOM SECTION C IN PWM OUTPUT |
| YELLOW/BLACK | BOOM SECTION C OUT PWM OUTPUT |
| BROWN/BLACK | ROTATE NOZZLE LEFT PWM OUTPUT |
| BLACK/RED | ROTATE NOZZLE RIGHT PWM OUTPUT |
| BLUE/RED | AGITATE (6A) PWM OUTPUT |
| ORANGE/RED | LOAD (6B) PWM OUTPUT |
| YELLOW/RED | HYDROSTAT A FWD CR OUTPUT |
| BROWN/RED | HYDROSTAT A REV CR OUTPUT |
| BLACK/BLUE | HYDROSTAT B FWD LOW CR OUTPUT |
| RED/BLUE | HYDROSTAT B REV LOW CR OUTPUT |
| ORANGE/BLUE | CLOG N.O. DIGITAL INPUT |
| YELLOW/BLUE | AGITATE SPEED 0-5V ANALOG INPUT |
| BROWN/BLUE | PUMP OUT 0-5V ANALOG INPUT |

ROUTINE MAINTENANCE

Clean transmitters regularly with a damp cloth and mild detergent.

Inspect electrical wiring for wear points or other damage. Repair as required.

Inspect all connections for looseness or corrosion. Tighten and/or "seal" as necessary.

MAINTENANCE PRECAUTIONS

When performing any inspection or maintenance work on the remote system, always exercise care to prevent injury to yourself and others or damage to the equipment. The following are general precautions, which should be closely followed in carrying out any maintenance work. Do not have hydraulic power available to the valves when performing electrical tests.

Never operate or test any function if any person is in an area where they could be hurt by being hit or squeezed by the hydraulic equipment.

Turn power off before connecting or disconnecting valve coils or other electrical loads.

TROUBLESHOOTING

This next section provides basic operator level troubleshooting for the GIGA AND MICRO REMOTE If, system. after following these instructions, the system still does not function, **KAR-TECH** contact your representative for further instructions or servicing.

TROUBLESHOOTING CHART

| PROBLEM | SOLUTION |
|-------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| No functions work | 1. Verify transmitter power source – battery, CAN cable, external supply, etc |
| | 2. Verify that receiver control module power source is present at its input connector |
| | 3. Check for proper system ground |
| | 4. Check the receiver or control module LED status display for functionality or errors |
| | 5. Check the hydraulic system |
| Certain functions do not work | 1. Check the wiring and connections from the receiver control module to the control module to the valve coil for the particular function that does not work |
| | 2. Check the receiver control module LED status display for possible fault or error indication |
| | 3. Check the hydraulic system |
| | 4. Check the electrical system |
| Functions operate intermittently | 1. Check for loose connections at the valve coil |
| | 2. Check the receiver control module LED status display for functionality or errors |
| | 3. Check the receiver antenna for damage and possible obstructions |
| | 4. Check the hydraulic system |

ERROR CODES

| ERROR | PROBABLE CAUSE |
|-------|-----------------------------------|
| 1 | RF COMMUNICATION PROBLEM |
| 2 | LOW SYSTEM VOLTAGE, LESS THAN 11V |
| 3 | HYDROSTAT A FWD OUTPUT ERROR |
| 4 | HYDROSTAT A REV OUTPUT ERROR |
| 5 | HYDROSTAT B FWD OUTPUT ERROR |
| 6 | HYDROSTAT B REV OUTPUT ERROR |
| 7 | BOOM ROTATE LEFT OUTPUT ERROR |
| 8 | BOOM ROTATE RIGHT OUTPUT ERROR |
| 9 | BOOM SECTION A UP OUTPUT ERROR |
| 10 | BOOM SECTION A DOWN OUTPUT ERROR |
| 11 | BOOM SECTION B IN OUTPUT ERROR |
| 12 | BOOM SECTION B OUT OUTPUT ERROR |
| 13 | BOOM SECTION C IN OUTPUT ERROR |
| 14 | BOOM SECTION C OUT OUTPUT ERROR |
| 15 | NOZZLE ROTATE LEFT OUTPUT ERROR |
| 16 | NOZZLE ROTATE RIGHT OUTPUT ERROR |
| 17 | AGITATE OUTPUT ERROR |
| 18 | LOAD OUTPUT ERROR |
| 19 | BOOM ROTATE LEFT BUTTON ERROR |
| 20 | BOOM ROTATE RIGHT BUTTON ERROR |
| 21 | BOOM SECTION A UP BUTTON ERROR |
| 22 | BOOM SECTION A DOWN BUTTON ERROR |
| 23 | BOOM SECTION B IN BUTTON ERROR |
| 24 | BOOM SECTION B OUT BUTTON ERROR |
| 25 | BOOM SECTION C IN BUTTON ERROR |
| 26 | BOOM SECTION C OUT BUTTON ERROR |
| 27 | NOZZLE ROTATE LEFT BUTTON ERROR |
| 28 | NOZZLE ROTATE RIGHT BUTTON ERROR |
| 29 | AGITATE SPEED INPUT ERROR |
| 30 | LOAD SPEED INPUT ERROR |
| 31 | WI-FI CHIP ERROR |

work

Error code explanations:

| 1 | Transmitter is off Transmitter went to sleep mode Interference in RF communication link |
|-------|-----------------------------------------------------------------------------------------------|
| 2 | System voltage is below 11V (12V system) |
| 3-18 | Short or open load/coil on output |
| 19-28 | No voltage present on button in transmitter |
| 29-30 | Input is over 5.4V and therefore in error |
| 31 | Wi-Fi chip has been damaged and wi-fi will not |

PARTS LIST

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| 3B3072A | MICRO RADIO TRANSMITTER |
| 3B3074A | GIGA RADIO TRANSMITTER |
| 3B3073A | RADIO RECEIVER |
| B20172A | MICRO WALL CHARGER |
| B20173A | MICRO CIGARETTE CHARGER |
| B20178A | GIGA MAGNETIC USB CHARGER |

There are no user-serviceable parts inside the transmitter or the receiver. Return the units for service.

Note: For operation with negative ground systems only.

WARNING:

The GIGA AND MICRO REMOTES must be operated in compliance with all applicable safety regulations, rules, and practices. Failure to follow required safety practices may result in death or serious injury.

The information, specifications, and illustrations in this manual are those in effect at the time of printing. We reserve the right to change specifications or design at any time without notice.

GIGA TRANSMITTER PICTORIAL











MICRO TRANSMITTER PICTORIAL



RECEIVER PICTORIAL







SPECIFICATIONS

TRANSMITTER

| Equipment Class | Part 15 Spread Spectrum Transmitter |
|------------------------------------------|-------------------------------------|
| FCC ID | P4U-MCT247 OR P4U-MCT241 |
| ICC (Industry Canada Certification) ID | 4534A-MCT247 OR 4534A-MCT241 |
| Power supply | 3.7V Rechargeable Battery |
| Fast charger temperature range | +5°C to +60°C |
| Operating temperature - Radio | -40°C to +85°C |
| Storage temperature | -40°C to +100°C |
| RF Frequency | 2.4GHz |
| RF Transmit power (EIRP) | 100 mW |
| LCD display operating range (if equipped | ed)20°C to +70°C |
| Vibration | |
| Shock | |
| NEMA | |

RECEIVER

| Power supply voltage | 9-30VDC |
|--------------------------------------------------------|-------------------------------------|
| Operating temperature | -40° C to $+85^{\circ}$ C |
| Storage temperature | -40° C to $+100^{\circ}$ C |
| Outputs 5.0A max each for momentary, 3.0A max each for | or latched, sourcing |
| System | 20A system max |
| Digital Inputs (when equipped) | supply voltage |
| Analog Inputs (when equipped) | 0-5VDC |
| RF Frequency | 2.4GHz |
| Vibration | 3G to 200Hz |
| Shock | 100G |
| NEMA | 4X |

INSTRUCTION TO THE USER (GIGA AND RECEIVER)

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

* Reorient or relocate the receiving antenna.

* Increase the separation between the equipment and receiver.

* Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

* Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC CAUTION: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

INDUSTRY CANADA STATEMENTS

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée quivalente (p.i.r.e.) ne dépassepas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

OEM Responsibilities to comply with FCC and Industry Canada Regulations

The MCT247 Transceiver has been certified for integration into products only by the OEM integrators under the following conditions:

This device is granted for use in Mobile and Portable configurations per Part 2.1091(b) in which the antennas used must be installed to provide a separation distance of at least 3.6cm from all person and not be co-located with any other transmitters except in accordance with FCC and Industry Canada multi-transmitter product procedures.

As long as the two conditions above are met, further transmitter testing will not be required. However the OEM integrator is still responsible for testing their end product for any additional compliance requirements required with this module installed.

If the above conditions are not met, then the FCC and Industry Canada authorizations are no longer valid and the FCC ID and IC Certification Number cannot be used on the final product. In these cases the OEM integrator is responsible for re-evaluating the end product and obtaining a separate FCC and Industry Canada authorization.

Recertification is also needed for all other operating configurations, including portable configurations with respect to part 2.1093 and different antenna configurations.

EUROPE

CE NOTICE

This device has been tested and certified for use in the European Union. See the Declaration of Conformity (DOC) for specifics.

If this device is used in a product, the OEM has the responsibility to verify compliance of the final product to the EU standards. A declaration of Conformity must be issued and kept on file as described in the Radio and Telecommunications Terminal Equipment (R&TTE) Directive.

The 'CE' mark must be placed on the OEM product per the labeling requirements on the Directive.

Declaration of Conformity (DOC)

This DOC can be downloaded from the <u>www.kar-tech.com</u>.

INSTRUCTION TO THE USER (MICRO)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The module can be installed or integrated in mobile or fix devices only. This modular cannot be installed in any portable device, for example, USB dongle like transmitters is forbidden.

This module complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This module must be installed and operated with a minimum distance of 20 cm between the radiator and user body.

If the FCC identification number is not visible when the module is installed inside another device, then the outside of the device into which the module is installed must also display a label referring to the enclosed module. This exterior label can use wording such as the following: "Contains Transmitter Module FCC ID: P4U-MCT241"

When the module is installed inside another device, the user manual of this device must contain below warning statements;

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The devices must be installed and used in strict accordance with the manufacturer's instructions as described in the user documentation that comes with the product

INDUSTRY CANADA STATEMENTS

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée quivalente (p.i.r.e.) ne dépassepas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

OEM Responsibilities to comply with FCC and Industry Canada Regulations

Operation is subject to the following two conditions:

(1) This device may not cause interference; and

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil est conforme aux CNR exemptes de licence d'Industrie Canada . Son fonctionnement est soumis aux deux conditions suivantes :

(1) Ce dispositif ne peut causer d'interférences ; et

(2) Ce dispositif doit accepter toute interférence, y compris les interférences qui peuvent causer un mauvais fonctionnement de l'appareil.

IC Radiation Exposure Statement

The modular can be installed or integrated in mobile or fix devices only. This modular cannot be installed in any portable device, for example, USB dongle like transmitters is forbidden.

This modular complies with IC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This modular must be installed and operated with a minimum distance of 20 cm between the radiator and user body. Cette modulaire doit être installé et utilisé à une distance minimum de 20 cm entre le radiateur et le corps de l'utilisateur.

If the IC number is not visible when the module is installed inside another device, then the outside of the device into which the module is installed must also display a label referring to the enclosed module.

This exterior label can use wording such as the following: "Contains IC: 4534A- MCT241"

When the module is installed inside another device, the user manual of this device must contain below warning statements:

1. This device complies with Industry Canada's license-exempt RSSs.

Operation is subject to the following two conditions:

(1) This device may not cause interference; and

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

2. Cet appareil est conforme aux CNR exemptes de licence d'Industrie Canada . Son

fonctionnement est soumis aux deux conditions suivantes :

(1) Ce dispositif ne peut causer d'interférences ; et

(2) Ce dispositif doit accepter toute interférence, y compris les interférences qui peuvent causer un mauvais fonctionnement de l'appareil.

The devices must be installed and used in strict accordance with the manufacturer's instructions as described in the user documentation that comes with the product.

EUROPE

CE NOTICE

This device has been tested and certified for use in the European Union. See the Declaration of Conformity (DOC) for specifics.

If this device is used in a product, the OEM has the responsibility to verify compliance of the final product to the EU standards. A declaration of Conformity must be issued and kept on file as described in the Radio and Telecommunications Terminal Equipment (R&TTE) Directive.

The 'CE' mark must be placed on the OEM product per the labeling requirements on the Directive.

Declaration of Conformity (DOC)

The device complies with RF specifications when the device used at your body.

Caution: Must use the original antenna. Other antennas are not allowed to be used.

The device according to the regulation in Directive 1999/5/EC and complies with standards as follow:

| EMC (Article 3.1b) | ETSI EN 301 489-1 V 1.9.2 | Report No.: CTL1603030544-WE |
|-----------------------|--------------------------------------------------------|-------------------------------|
| | ETSI EN 301 489-17 V2.2.1 (2012-09) | |
| Radio (Article 3.2) | ETSI EN 300 328 V1.8.1 | Report No.: CTL1603030544-WR |
| Safety (Article 3.1a) | EN 60950-1:2006+A11:2009+A1:2010+A12:2011+A2:2013 | Report No.: CTL1603030544-WS |
| Health (Article 3.1a) | EN 62209-2:2010 | Report No.: CTL1603030544-SAR |
| | EN 50566:2013 | - |
| | [Titles, dates of publication of documents mentioned] | |

CE0700